

Routine Maintenance for Super Seal 4700 Doors

1. Visual Inspection (Daily)

- Check hinges, pivots, and hardware for wear or looseness.
- Inspect gasketing and seals for cracks or gaps.
- Look for damage to panels or windows.

2. Lubrication (Monthly or as needed)

- Apply **general-purpose grease (BR2+ or food-grade)** to pivot points and hinges.
- Avoid over-lubricating—wipe excess grease to prevent dirt buildup.

3. Hardware Tightening

- Ensure all bolts, screws, and anchors are secure.
- Use **serviceable thread-lock compound** on fasteners if needed.

4. Cleaning

- Clean panels with mild detergent and water.
- Avoid abrasive cleaners that can damage the finish.

5. Operational Check

- Open and close the door several times to confirm smooth movement.
- Check for binding or misalignment, adjust pivots if necessary, or replace excessive wear or broken parts.

6. Preventive Measures

- Replace worn bumpers, seals, or gaskets promptly as needed.
- Inspect framing for corrosion or structural issues.