


Series 9010-3 – Off-Wall Mount Strip Curtain

INSTALLATION INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE INSTALLING CURTAIN. SUPER SEAL MFG. LTD. WILL NOT BE HELD RESPONSIBLE FOR IMPROPER INSTALLATION OF ANCHORING DEVICES, OR FOR INSTALLATION INTO AGED OR UNSOUND CONCRETE, CONCRETE BLOCK, OR OTHER WALL OR FLOOR MATERIAL WHICH MAY RESULT IN PREMATURE PRODUCT WEAR, PRODUCT FAILURE, PROPERTY DAMAGE, OR PERSONAL INJURY.



Note: Before Installation see hardware list at back of this manual (page 6).

1. Mark Wall For Installation of Off-Wall Brackets.

- Using a level, make a vertical line parallel to doorjamb at a distance of 6 1/4" out from jamb. Line should extend approx. 9" above lintel, and approx. 13" below lintel line. Repeat for other side (Fig. 1).
- Using a level, make a horizontal line out from lintel height across vertical lines. Repeat for other side (Fig. 1).




FIG. 1

2. Prepare Off-Wall Brackets

- Insert track bolts into PVC flat bar of brackets (Fig. 2)
- Tape backside of flat bar to hold track bolts in place (Fig. 3)




FIG. 2




FIG. 3

3. Attach Off-Wall Brackets To Wall.

- Hold off-wall bracket against wall so that outer edge is flush with vertical line, and top of horizontal angle is flush with horizontal line (Fig. 4).
- Drill through mounting holes in off-wall bracket using Ø 3/8" concrete drill bit.
- Insert 3/8" sleeve anchors and tighten with 1/2" socket driver bit (Fig. 4).




FIG. 4

4. Prepare Cross-Bar

- a. Insert track bolts into crossbar (Fig. 5).
- b. Tape backside of flat bar to hold track bolts in place (Fig. 6).




FIG. 5




FIG. 6

5. Attach Cross-bar To Off-Wall Brackets

- a. Place cross-bar on top of off-wall brackets so that mounting holes on both ends line up with hole on off-wall brackets (Fig. 7).
- b. Insert 1/2" bolt into mounting hole of crossbar and through hole in off-wall bracket (Fig. 7).
- c. Screw on 1/2" hex nut with 1/2" lock washer. Hand tighten.
- d. Finish tightening using 3/4" socket driver bit.





FIG. 7

6. Attach Side PVC Strips


- a. Attach side PVC strips to sides of off-wall brackets (Fig. 8).
- b. Secure PVC strips into position using 1/4" fender washers and 1/4" hex nuts, using 7/16" socket driver bit (Fig. 8).




CAUTION: Make sure you select the correct PVC strips.

7. Attach Front PVC Strips


- a. Attach front PVC strips to cross-bar (Fig. 9).
- b. Secure PVC strips into position using 1/4" fender washers and 1/4" hex nuts (Fig. 9), using 7/16" socket driver bit.




Note: Refer to Figs. A-D for proper PVC strip layout.




6" STRIPS
FIG. A



8" STRIPS
FIG. B



12" STRIPS
FIG. C



16" STRIPS

FIG. D

The Following Lists Cover Basic Installation, Not Including Options.

Components List (Per Assembly)

No.	Description	Qty.
1	PVC Off-Wall Brackets – Left (9010)	1
2	PVC Off-Wall Brackets – Right (9010)	1
3	PVC Strips	*

*Quantities dependent on customer specifications

Hardware List (Per Assembly)

No.	Description	Qty.
1	1/4" (20) HEX NUT-ZINC	*
2	1/4" B.S. FENDER WASHER-ZINC	*
3	1/4" (20) X3/4" TRACK BOLT-ZINC	*
4	1/2" (13) HEX NUT-ZINC	*
5	1/2" B.S. LOCK WASHER-ZINC	*
6	1/2" (13) X1 1/4" HEX BOLT-ZINC	*
7	3/8" X1 7/8" SLEEVE ANCHOR-ZINC	8

*Quantities dependent on customer specifications

Recommended Tools

No.	Description	Qty.
1	Tape Measure	1
2	Plumb line or Level	1
3	Pencil or Marker	1
4	Square	1
5	Power Drill	1
6	Hammer Drill	1
7	3/8" Masonry Drill Bit	1
8	1/2" Socket Driver Bit	1
9	7/16" Socket Driver Bit	1
10	3/4" Socket Driver Bit	1